

Molecular Complexes of Agomelatine- Phosphoric Acid:

Crystal Structure Determination and Phase Transformation Kinetics by Non-Ambient Powder XRD

Raja Sekhar Voguri; Praveen Chappa;
Rama Reddy Chirla; Archan Dey

This document was presented at PPXRD - Pharmaceutical Powder X-ray Diffraction Symposium

Sponsored by The International Centre for Diffraction Data

This presentation is provided by the International Centre for Diffraction Data in cooperation with the authors and presenters of the PPXRD symposia for the express purpose of educating the scientific community.

All copyrights for the presentation are retained by the original authors.


The ICDD has received permission from the authors to post this material on our website and make the material available for viewing. Usage is restricted for the purposes of education and scientific research.



PPXRD Website – www.icdd.com/ppxrd

ICDD Website - www.icdd.com

Background of Development



- ✓ Novel **antidepressant** developed by Servier Laboratories
- ✓ Thermodynamically **stable form-II**
- ✓ Up to now, **six** polymorphs and several other **solvates/co-crystal** (Acetic acid, Ethylene glycol, Urea, Citric Acid, Oxalic acid etc) are known
- ✓ Biopharmaceutics Classification System (BCS) **class: II**
- ✓ Form-I suffers from **industrial process feasibility** aspect
- ✓ Co-former **screening**, Phosphoric acid **selected**:
 - Biopharmaceutical acceptable excipient
 - Processeability
 - Stability

Decreasing Solubility

Acetic acid Solvate

(P2₁/c, Z'=1
Mp: 76° C)

Form III

(Pna2₁, Z'=1
Mp: 100.4° C)

Form I

(Pca2₁, Z'=2
Mp: 99.1° C)

Form II

(P2₁/c, Z'=2
Mp: 109.3° C)

References: EP 2743 255 A1; Cryst. Growth & Des: 2011, 11, 466; Cryst. Growth & Des: 2012, 12, 2226; and AJPS: 2013, 8, 181


Problem Statement: *Solid-State Impurity*

Preparation Process


Dissolving
Agomelatine in a
solvent like EtOAc



Adding H_3PO_4 to the
solution in step




Isolating and drying
the product



Batch-to-Batch Variation


- Process related
- Polymorphic impurity; any existing forms.
- Detailed investigation

Indexing of P-XRD Data



- ✓ Indexing is possible with (1:1) AGL:H₃PO₄ molecular complex.
- ✓ Extra peaks from-II is coincident, missing of main characteristic peaks like 18.6° 2θ.
- ✓ Possibility of new crystalline phase.


Thermal Studies: DSC, TGA and Hot stage Microscopy




- ✓ Solid-solid phase transition (≈42° C), supported by hot stage microscopy; no change in morphology.
- ✓ AGL-P mp (118.0° C) is higher than AGL form-II (109.3° C).

Variable Temperature PXRD Studies

VT-PXRD




Heat-Cool-DSC




✓ Solid-solid phase transition leads to **new polymorph** (HT-Form). They are **enantiotropic** in nature; crystallization of RT-form happens at $\approx 22^\circ \text{C}$.

Kinetic Studies by *DSC: Non-isothermal*

RT-Form → HT-Form



HT-Form → RT-Form



Model	RT-Form → HT-Form		HT-Form → RT-Form	
	Activation Energy (KJ/Mole)	Average	Activation Energy (KJ/Mole)	Average
Kissnger	-41.0	-43.6	-36.2	-33.8
Augies	-43.6		-33.8	
FWO	-46.2		-31.4	

Crystal Determination From Powder X-Ray Diffraction

Indexing

- Unit Cell Parameters Determination
- Space Group Search
- Refinement


Structure Solution

- **Model Selection**
- Solution (Simulating Annealing)


Structure Refinement


- Rietveld Refinement
- Analysis of Crystal Structure in terms of Hydrogen Bonding Interaction
- Fine Tune the Structure
- Refinement

Appropriate Model Selection is the key part of successful structure determination for multi-components crystal


 MATERIALS STUDIO | Reflex

 Reflex

 Polymorph Prediction



AGL-Acetic Acid
(Available Crystal Structure)




AGL-P
(Model)

- Crystal Structure Prediction with indexed Space group
- Model selection on the basis of cell dimension and H-bonding interaction profile


Structure Solution with the selected model

Data Collection Strategies

RT-Form




HT-Form



- ✓ Anton-paar Non-Ambient stage data **were not suitable** for Structure Determination, due to **extensive preferred orientation**.
- ✓ Data collection for meta-stable HT-Form in transmission mode is challenging. RT-Form is converted to HT-Form externally and data is collected in **foil-transmission mode**. Still, few peaks of RT-Form observed; excluded for structure determination.


Crystal Structure of RT-Form



Crystallographic Data

Empirical Formula	$C_{15}H_{17}NO_2 \cdot H_3PO_4$
Crystal System	Monoclinic
Space Group	$P2_1/c$
a (Å)	21.724(4)
b (Å)	4.599(1)
c (Å)	17.173(3)
β (°)	112.368(1)
V (Å ³)	1584.65
Z, Z'	4, 1
Dc (g/cm ³)	1.431


- ✓ Good fitting of final Rietveld refinement plot.
- ✓ (1:1) AGL-P molecular complex.
- ✓ Crystal packing: segregation of aromatic part and hydrophilic phosphoric part.
- ✓ AGL and PA forming 1-D chain running along c axis.




Crystal Structure of HT-Form

Crystallographic Data


Empirical Formula	$C_{15}H_{17}NO_2 \cdot H_3PO_4$
Crystal System	Monoclinic
Space Group	$P2_1/c$
a (Å)	22.413(1)
b (Å)	4.598(2)
c (Å)	17.797(9)
β (°)	111.468(2)
V (Å ³)	1706.99
Z, Z'	4, 1
Dc (g/cm ³)	1.328



- ✓ Good fitting of final Rietveld refinement plot.
- ✓ (1:1) AGL-P molecular complex.
- ✓ Crystal packing: segregation of aromatic part and hydrophilic phosphoric part.
- ✓ PA forming a dimer that connected with AGL and forming 1-D chain, running along c axis.



Crystal Structure Analysis




CrystalEngComm
2013,15, 8941

Possibility of salt formation of AGL-PA
is low

- as being with **weakly ionizable** amide functionality
- with pka difference is also ≤ 1
- Strong H-Bond length $\leq 2.55\text{\AA}$ can be used as salt/co-crystal criteria


Hydrogen bond Matrices	Bond Length (\AA), Angle ($^\circ$)	
	RT-Form	HT-Form
C=O....(H)O-P	2.56, 144	2.46, 167
P=O....(H)O-P	2.52, 145	2.4, 141
C-N(H)....O(H)-P	3.11, 130	3.24, 145/ 3.07, 142
C-N(H).... O=P	2.88, 139	-
P-O....(H)O-P	2.73, 154	2.44, 125

RT-Form



The common
H-N-C=O
torsion angle of
AGL is in the
range of 162-
180°

HT-Form



Summary and Conclusions

- ✓ Crystal Structure Determination confirms
 - Both the molecular complexes of (1:1) molecular complexes of AGL-P are **co-crystal**, showing enantiotropic **polymorphism**.
- ✓ Correlation between kinetics and molecular level structural understanding reveals
 - **Conformational switching** is the triggering factor of solid-solid phase transformation.
 - At ambient temperature half life of **RT-form** is **more than HT-form**.
- ✓ The proposed **protocol of model selection** with help of Polymorph prediction could simplify the co-crystal structure determination from PXRD data.
- ✓ AGL-P co-crystal is a “pharmaceutical co-crystal” and **the best** alternative of AGL Form-II in terms of enhance processability as well as stability with comparable solubility.

Acknowledgement

API Project Team (Process Understanding)

- D Vamshi Krishna (Project Manager)
- Vujjini Satish Kumar (Scientist)
- Katkam Srinivas (Delivery Manager)

IPM (Discussion)

- Ch Ramesh (Director)
- A Ashok (Scientist)

Formulation Project Team (Solubility Data)

- Jigar A vyas (Scientist)
- Jaypal Reddy (Analytical Scientist)

Advanced Analytical Technology Team (Discussion and Support)

- Maheswararao Karanam (Analytical Scientist)
- Ioorika Lamare (Analytical Scientist)
- Amjad Basha Mohammad (Principal Scientist)
- V Ranga Reddy (Principal Scientist)
- Srinivasan Duraiswamy (Director)
- K Vyas (Ex-Vice President)

Thanks....